

**Product Information:**

# Wet Room Adhesive 216

**Ready-mixed for mounting of fibre glass web & felt in wet rooms**

**General description and applications:**

Wet Room Adhesive 216 is water-based adhesive, developed for mounting fibre glass web and fibre glass felt in wet rooms. Suitable for surfaces as for ex. gypsum board, concrete, plaster, wood etc.

The adhesive is also suitable for mounting of fibre glass web and –felt at non-absorbent surface, including ceramic tiles etc.

The product has been tested and approved as a product with low emission according to the M1-classification.

The product is registered in the database for construction products that can be included in the Nordic Ecolabelled construction.



**Physical / chemical properties:**

**Adhesive:**

- Type: Modified starch & Poly acrylate dispersion
- Colour: White
- Consistency: Creamy
- Solids content: Approx. 21 %
- Density: Approx. 1,0 Kg/L
- Shelf life: Minimum 12 months in tightly closed packing if stored cool and dry. The product must be protected from freezing.

**Packaging:**

Item no	Size
4671	1 ltr
4672	2.5 ltr
46731	5 ltr square
4675	15 ltr square



## Directions for use:

- Preparation:** *The foundation must be clean, dry, solid, non-smudging and free from wall-paper remnants.*
- Non-absorbent and painted foundations are sanded and washed with a cleaning agent. Especially when hanging non-absorbent coverings, it is important that the foundation is absorbent.*
- On smudging or very absorbent surfaces must be primed with Plaster Primer 224 or Plaster Primer Gel Extra 228 after cleaning.*
- Dilution:** *The adhesive is stirred well before use. If necessary, the adhesive can be diluted with water.*
- Application temperature:** *15 °C to 30 °C, best at room temperature.*
- Application:** **Mounting of fibre glass web and fibre glass felt.**  
*The adhesive is applied in an even layer to the wall, using brush, roller or spray application. Do not apply adhesive on a large area than the material can be mounted while the adhesive is still wet.*
- Mounting of foamed wallpaper:**  
*The adhesive is applied in an even layer on the back side of the wallpaper, where it must soften the paper before mounting. Avoid adhesive in the front side of wallpaper, any glue that comes to the front, removed depending on paper quality with a damp cloth or sponge.*
- Always avoid adhesive on the front of the wall covering material.*
- Yield:** *4 - 5 m<sup>2</sup>/ltr.*
- Drying time:** *Normally approx. 24 hours, depending on room temperature and air humidity.*
- Treatment:** *After complete drying, the fibre glass web/felt can be painted. Please note that the adhesive is moisture resistant but must be protected from direct influence of water.*
- Always follow the instructions of the wall covering supplier.**
- Cleaning:** *Wash hands and skin with soap and water.  
Remove stains and spots immediately with a damp cloth.  
Clean tools with lukewarm water.  
Dried adhesive can be removed mechanically or dissolved by soaking in water*

## Health and safety:

*For further information on safety, please refer to product safety data sheet.*

*The information and data contained in this Product Information sheet are based on extensive laboratory testing and our practical experiences and are meant for helping the user to find optimum working methods. As the conditions at the user are beyond our control, we make no warranties concerning the results, achieved by the products. The information's in this Product Information sheet are typical values, intended as a guideline. They should not be regarded as product specifications. Please also refer to our standard sales conditions and terms of delivery.*

**DANA LIM A/S - KØBENHAVNSVEJ 220 - DK-4600 KØGE – DENMARK – INFO@DANALIM.DK  
PH. (+45) 56 64 00 70 - TECHNICAL SERVICE PH. (+45) 56 64 00 75**